

TFE™ - PIPE THREAD SEALANT WITH PTFE

[Download PDF](#)[Printable Page](#)[Email This Page](#)[Save To Favorites](#)

TFE™ is a superior-grade, non-hardening, heavy-duty pipe thread sealant that is easy to-apply. Formulated to a thick paste consistency, its fortified with an extra amount of PTFE and PTFE materials to give a positive seal with less effort. Because of its unique solids content, **TFE** fills thread imperfections and provides leak-proof joints that seal for the life of the connection.

Features and Benefits:

- Heavy-duty sealant
- Contains no solvents
- Seals immediately, no waiting
- Non-staining, non-corrosive, non-hardening, non-toxic
- Non-dripping, can be applied to newly cut hot threads
- Prevents corrosion, seizing and galling
- UL Classified and NSF Registered
- UL Classified for fire protection sprinkler systems

Temperature/Pressure Ranges: Withstands temperatures to 500°F (260°C) and pressures to 10000 psi (liquid), 2000 psi (gas)

Applications: Recommended for pipes carrying water, steam, LP and natural gas, refrigerants, solvents, caustics, dilute acids, oils, diesel fuel and ethanol. Use on all pipe threads made of cast iron, malleable, brass, copper, and stainless steel. Designed for use by all pipe fitters, fabricators, plumbers, and mechanical contractors. Please call 1-800-991-1106 for 55gal Drum price.

* Point of Purchase Display

[Request Information](#)

Sort by

Position

Display

100

Item #	Item Name	Size	Packaging Type	Color	Price	
14002	TFE™ PIPE THREAD SEALANT with PTFE	2 oz	Brush Top	Off White	\$6.03	Add to cart
14003	TFE™ PIPE THREAD SEALANT with PTFE	3 oz	Tube	Off White	\$7.41	Add to cart
14005	TFE™ PIPE THREAD SEALANT with PTFE	0.25 pint	Brush Top	Off White	\$8.27	Add to cart